

## Part List

- mechanical -



*Xperia XA2 Plus*  
**H3413,H4413,H4493**

CONTENTS

1 Part List ..... 3

2 History ..... 12













## 1 Part List







The following parts are available for order in 'Hybris'.

















The 'Hybris' name of a part may often be complex and even confusing, so the name of certain parts mentioned in the Working Instructions, Repair Movies and Troubleshooting Guide are often referred to by a simple descriptive name for better understanding.

















Both names (designations) will in that case be included in this Part List, where the name being used in the documents mentioned above is underlined, e.g. Battery Cover.



















RLC, Reversed Logistic Classification column for replaced part handling, See the Spare part handling chapter in Mechanical/Generic Repair Manual (00154064).



















Designation	Part No.	RLC	Part	Location
Adhesive Antenna Spring FPC	XXCQ100494W	C		
Adhesive Battery Cover Bottom	306Q2AQ0400	C		
Adhesive Battery Cover Left/Right	306Q2AQ0500	C		
Adhesive Battery Cover Top	306Q2AQ0300	C		
Adhesive Battery Left	306Q2AQ0A00	C		
Adhesive Battery Right	306Q2AQ0C00	C		

Designation	Part No.	RLC	Part	Location
Adhesive Camera Key FPC	XXCQ100495W	C		
Adhesive Ear Speaker	306M24S0600	C		
Adhesive FP Module	XXCQ100248W	C		
Adhesive LCM	306Q2AQ0800	C		
				
Adhesive NFC	XXCQ100496W	C		
Adhesive Power_Volume Key FPC	XXCQ100493W	C		
Adhesive Sidekey FPC Main	XXCQ100492W	C		














Designation	Part No.	RLC	Part	Location
Adhesive Vibrator	XXCQ100243W	C		
Audio Jack FPC Assy	21BY4201F00	C		
Battery	1308-3586	B		
<u>Battery Cover Assy</u> Battery Cover Assy Black Battery Cover Assy Gold Battery Cover Assy Green Battery Cover Assy Silver	78PC5200010 78PC5200030 78PC5200040 78PC5200020	B		
Bracket Main Camera	305A24S0600	C		
<u>Cap Tray SIM/SD Dual</u> Cap Tray SIM/SD Dual Black Cap Tray SIM/SD Dual Gold Cap Tray SIM/SD Dual Green Cap Tray SIM/SD Dual Silver	306J2AQ0100 306J2AQ0300 306J2AQ0400 306J2AQ0200	C		
<u>Cap Tray SIM/SD Single</u> Cap Tray SIM/SD Single Black	306J2AQ0500	C		
Conductive Tape Sub Antenna	306A2AQ0300	C		

Designation	Part No.	RLC	Part	Location
Contact Clip Speaker Box	305524S0200	C		
Copper Foil Battery Cover	306F2AQ0300	C		
Copper Foil Front Camera	306F2AQ0400	C		
CU Label	XXKS100968W	C		
CU Label Tray	306L2AQ0600	C		
<u>Display Cover Assy</u> Display Cover Assy Black Display Cover Assy Gold Display Cover Assy Green Display Cover Assy Silver	78PC5100010 78PC5100030 78PC5100040 78PC5100020	B		
Ear Speaker	C/22400001600	C		
<u>FP Module Assy</u> FP Module Assy Black FP Module Assy Gold FP Module Assy Green FP Module Assy Silver	76730003P00 76730003R00 76730003S00 76730003Q00	B		











Designation	Part No.	RLC	Part	Location
Front Camera	C/76510003100	B		
Gasket BtB FP Module	303M2AQ0700	C		
Gasket BTB Front Cam&AJ	303M2AQ0F00	C		
Gasket BTB LCM	303M2AQ0600	C		
Gasket BTB Sidekey FPC	303M2AQ0400	C		
Gasket BTB Sub PBA	303M2AQ0300	C		
<u>Key Camera</u> Key Camera Black Key Camera Gold Key Camera Green Key Camera Silver	31252AQ0900 31252AQ0B00 31252AQ0C00 31252AQ0A00	C		
<u>Key Power_Volume</u> Key Power_Volume Black Key Power_Volume Gold Key Power_Volume Green Key Power_Volume Silver	31252AQ0D00 31252AQ0F00 31252AQ0G00 31252AQ0E00	C		
<u>Main Antenna Speaker Box</u> Main Antenna Speaker Box H3413/H4413 Main Antenna Speaker Box H4493	22500005C00 22500005B00	C		

Designation	Part No.	RLC	Part	Location
Main Camera	C/76510002300	B		
<u>Main Camera Lens Assy</u> Main Camera Lens Assy Black Main Camera Lens Assy Gold Main Camera Lens Assy Silver	78PC5300010 78PC5300030 78PC5300020	C		
Mylar Battery FPC	306L24Q0200	C		
NFC Antenna	2300BY42100	C		
RF Cable Black	C/73200002300	C		
RF Cable White	C/73200002400	C		
Rubber 2nd MIC	302A2AQ0400	C		
Rubber Main Camera	302A2AQ0200	C		
Rubber PL Sensor	302A24S0100	C		



Designation	Part No.	RLC	Part	Location
Screw CROSS M1.2 L2.71 Black	2700000A400	C		
				
				
Screw TORX M1.4 L3.24 Silver	2700000A300	C		
				
<u>Side Panel Keys</u> Side Panel Keys Black Side Panel Keys Gold Side Panel Keys Green Side Panel Keys Silver	254F2AQ0D00 254F2AQ0F00 254F2AQ0G00 254F2AQ0E00	C		
<u>Side Panel SIM/SD</u> Side Panel SIM/SD Black Side Panel SIM/SD Gold Side Panel SIM/SD Green Side Panel SIM/SD Silver	254F2AQ0900 254F2AQ0B00 254F2AQ0C00 254F2AQ0A00	C		
Sidekey FPC Assy	78PC5400010	B		

Designation	Part No.	RLC	Part	Location
<u>Speaker Mesh</u> Speaker Mesh Black Speaker Mesh Gold Speaker Mesh Green Speaker Mesh Silver	254F2AQ0500 254F2AQ0700 254F2AQ0800 254F2AQ0600	C		
Speaker Sponge	306M2AQ0C00	C		
Sponge 1st Mic	303M2AQ0B00	C		
Sponge 1st Mic Hole	303M2AQ0E00	B		
Sponge Battery Connector	303M2AQ0800	C		
Sponge Notification LED	303M2AQ0A00	C		
Spring Antenna	30552AQ0300	C		 

Designation	Part No.	RLC	Part	Location
Sub Antenna	23A1BY42100	C		
<u>Sub PBA Assy</u> Sub PBA Assy H3413/H4413 Sub PBA Assy H4493	78PC5500020 78PC5500010	B		
Vibrator	29300001Q00	C		
Water Intrusion Label	82KB600001W	C		
Water Intrusion Label Rectangle	82BY4200500	C		

## 2 History

Rev.	Date	Changes / Comments
1	2018-Aug-16	Initial release