

Repair Movies

- mechanical -



Xperia XZ3

H8416, H9436 (Dual SIM), H9493 (Dual SIM)

CONTENTS

1	Disassembly Movie	3
1.1	Disassembly	3
2	Reassembly Movie	4
2.1	Reassembly	4
3	Revision History	5

To view the embedded repair movies in this document, video play back application such as Media Player is required.

If the movies appear to be jerky or blurred when viewing on-line, this is probably caused by the connection speed being too slow.

In that case, right-click with the mouse on the document name and select Save Target As to download the repair movie document for off-line viewing.

The Repair Movies is not substitute information of disassembly and reassembly in the Working Instruction, but it is supplemental information.

When you watch the movies, refer to the Working Instruction simultaneously.

1 Disassembly Movie

1.1 Disassembly

Double click the icon to play back the disassembly movie. → 

Note!

Refer to Working Instruction (1317-8697) for the details.

2 Reassembly Movie

2.1 Reassembly

Double click the icon to play back the reassembly movie. → 

Note!

Reassembly Movie doesn't include the following procedures;

- *Usage of Generic Wheel Press Tool*
- *Usage of Press Tool for Bending Camera FPC*

Refer to Working Instruction (1317-8697) for the details.

3 Revision History

Rev.	Date	Changes / Comments
1	2018-Sep-14	Initial release