

Part List

- mechanical -



Xperia™ Z2 Tablet

SGP511,SGP512,SGP521,SGP541,SGP551,SGP561

1	Part List	3
2	Revision History	12













1 Part List

The following parts are available for order in 'E-star'.

The 'E-star' name of a part may often be complex and even confusing, so the name of certain parts mentioned in the Working Instructions, Repair Movies and Troubleshooting Guide are often referred to by a simple descriptive name for better understanding.

Both names (designations) will in that case be included in this Part List, where the name being used in the documents mentioned above is underlined, e.g. Battery Cover.

RLC, Reversed Logistic Classification column for replaced part handling, See the Spare part handling chapter in Mechanical/Generic Repair Manual 1220-1333).













Designation	Part No.	RLC	Part	Location
Adhesive Battery	1278-2869	C		
Adhesive Panel Bottom Left L	1280-4591	C		
Adhesive Vibrator	1279-4780	C		
Adhesive WR Window LCD	1278-2898	C		
Ant DTV Black	1278-0132	C		
Audio Jack Flex Audio Jack Flex Audio Jack Flex SGP511,512	1277-2509 1279-9434	C		

















Designation	Part No.	RLC	Part	Location
Battery	1277-3631	B		
BT + WLAN + GPS Antenna	1278-0152	C		
Camera 2 MPixel	1277-4356	B		
Camera 8 Mpixel	1277-4258	B		
Cap SIM Cap SIM Assembly Black Cap SIM Assembly White	1278-2968 1278-3059	C		
Cap SP Assembly	1278-2878	C		
Cap USB Cap USB Assembly Black Cap USB Assembly White	1278-2973 1278-3070	C		
Carrier Frame Chat Cam	1278-2865	C		

Designation	Part No.	RLC	Part	Location
Carrier Frame Sub PBA	1278-2885	C		
Cling Window Front (SGP561)	1285-8930	C		
Cushion Back Vol L	1278-2883	C		
Cushion Chat Cam	1278-2866	C		
Cushion Relay LCD	1280-4588	C		
Cushion SPK R	1283-9225	C		
Display Assembly RoW	1281-2275	A		
<u>Diversity Antenna</u> Diversity Antenna Diversity Antenna SGP511,512 Diversity Antenna SGP561	1278-0115 1278-0123 1278-0116	C		












Designation	Part No.	RLC	Part	Location
Frame DTV Frame DTV Black Frame DTV White	1278-2855 1278-3052	C		
Frame SIM (N/A SGP521,541,561)	1279-2429	C		
Gasket Conductive FPC	1278-2889	C		
Graphite Sheet PBA	1278-2860	C		
GPS Antenna (SGP561)	1278-0148	C		
Holder Audio Jack	1278-2870	C		
Holder Chat Cam	1278-2863	C		
Holder LCD Relay BtB	1278-2914	C		

Designation	Part No.	RLC	Part	Location
Holder Main CAM	1278-2884	C		
Holder PBA Screw	1278-2868	C		
Holder Vibrator	1278-2873	C		
Key Flex module Key Flex module Key Flex module SGP511,512	1277-2510 1279-9454	C		
Key Volume Key Volume Black Key Volume White	1278-2890 1278-3055	C		
Loudspeaker + Ear Speaker	1277-7138	C		
Magnetic charger connector Magnetic charger connector Black Magnetic charger connector White	1277-7571 1278-6823	C		
Magnetic charger flex Magnetic charger flex Magnetic charger flex SGP511,512	1277-2508 1279-9456	C		

Designation	Part No.	RLC	Part	Location
<u>Main Antenna</u> Main Antenna Main Antenna SGP511,SGP512 Main Antenna SGP561	1278-0101 1278-0109 1278-0106	C		
<u>Main Frame</u> Main Frame Black RoW Main Frame White RoW Main Frame Black SGP561	1281-6463 1281-6469 1281-6480	B		
NFC antenna	1277-8756	C		
<u>Panel Bottom Left L</u> Panel Bottom Left L Black Panel Bottom Left L White	1278-3003 1278-3078	C		
<u>Panel Bottom Left S</u> Panel Bottom Left S Black Panel Bottom Left S White	1278-2980 1278-3074	C		
<u>Panel Left Bottom</u> Panel Left Bottom Black Panel Left Bottom White	1278-2891 1278-3056	C		
<u>Panel Left Top</u> Panel Left Top Black Panel Left Top White	1278-2979 1278-3073	C		
<u>Panel Right</u> Panel Right Black Panel Right White	1278-2981 1278-3075	C		

Designation	Part No.	RLC	Part	Location
Panel Top Left Panel Top Left Black Panel Top Left White	1278-2997 1278-3077	C		
Panel Top Right Panel Top Right Black Panel Top Right White Panel Top Right Black SGP551	1278-2985 1278-3076 1279-7288	C		
Panel WR Bottom Panel WR Bottom Right Panel WR Bottom Right White	1278-2888 1278-3053	C		
Plate Audio Jack	1280-4573	C		
Plate USB	1278-2864	C		
Relay LCD Flex Relay LCD Flex Relay LCD Flex SGP511,512	1277-2516 1279-9464	C		
RF Cable	1277-5395	C		
Screw 1.4X3.5	1262-1965	C		

Designation	Part No.	RLC	Part	Location
Screw Len:2.0 Diam:1.4 M	1271-7553	C		
Screw M1.4X3.0	1262-3150	C		
Screw Other Len:1.8 Diam:1.4 M	1232-3272	C		
Sensor Flex Sensor Flex Sensor Flex SGP511,512	1277-2518 1279-9466	C		
Sheet Chat CAM	1284-5724	C		
Sheet Window LCD Audio JACK	1278-2908	C		
Sheet Window LCD SP	1278-2903	C		
Shield Vibrator	1281-0227	C		

Designation	Part No.	RLC	Part	Location
SIM Tray SIM Tray (N/A SGP511,512) SIM Tray nano (SGP561)	1277-7606 1279-4965	C		
SP Flex SP Flex SP Flex SGP511,512	1277-2517 1279-9465	C		
Sub PBA Sub PBA (N/A SGP511 and SGP512) Sub PBA SGP561	1277-6000 1277-6016	B		
Terminal DTV	1278-2854	C		
Water Indicator	1255-4136	C		
Vibrator	1264-2341	C		

2 Revision History

Rev.	Date	Changes / Comments
1	2014-Mars-18	Initial release
2	2014-Mars-22	Update of document in Footer
3	2014-April-11	Updated SGP551 Spare Parts Ant DTV Black and Panel Top Right Black SGP551
4	2014-July-01	Updated SGP561 spare parts 1277-6016, 12788-0106, 1278-0116, 1278-0148, 1279-4965, 1281-6480, 1285-8930