

Part List

- mechanical -



Xperia™ M, Xperia™ M Dual

C1904, C1905, C2004, C2005

CONTENTS

1 **Part List 3**

2 **Revision History 10**









1 Part List

















The following parts are available for order in 'E-star'.




The 'E-star' name of a part may often be complex and even confusing, so the name of certain parts mentioned in the Working Instructions, Repair Movies and Troubleshooting Guide are often referred to by a simple descriptive name for better understanding.

Both names (designations) will in that case be included in this Part List, where the name being used in the documents mentioned above is underlined, e.g. Battery Cover.

















RLC, Reversed Logistic Classification column for replaced part handling, See the Spare part handling chapter in Mechanical/Generic Repair Manual 1220-1333.

















Designation	Part No.	RLC	Part	Location
ANT Board	311NIK1201G	C		
Ant Speaker Gasket	56FNIK00000	C		
<u>Battery Cover Assy</u> Battery Cover Assy Black SS Battery Cover Assy Movistar ES Black SS Battery Cover Assy Orange FR/ES Black SS Battery Cover Assy Orange FR/ES White SS Battery Cover Assy Purple SS Battery Cover Assy White SS Battery Cover Assy Yellow SS Battery Cover Assy Black DSDS Battery Cover Assy Purple DSDS Battery Cover Assy White DSDS	1272-1741 1276-2889 1276-2874 1276-2875 1274-1136 1272-1742 1274-1137 1272-1744 1276-1389 1272-1745	C		
Camera Connector Mylar Tape	464NIK00103	C		



Designation	Part No.	RLC	Part	Location
Camera Gasket	56BNIK00002	C		
<u>Camera Key</u> Camera Key Black Camera Key White	1272-3813 1272-3816	C		
Coaxial Cable	2831002300A	C		
Diffusion Film	468NIK00002	C		
Display	35051009W00	A		
Earspeaker	F79624032003	C		
EarSpeaker Adhesive	56BNIK00003	C		
Flash LED Gasket	56DNIK00005	C		

Designation	Part No.	RLC	Part	Location
Front Cover Assy Front Cover Assembly Black Front Cover Assembly White	1272-3743 1272-3744	C		
Kapton Tape Display FPC	56GNIK00002	C		
Kapton Tape TP connector	56GNIK00000	C		
Label	1272-1354	C		
Light Bar Gasket	56DNIK00011	C		
Light Pipe Sensor	468NIK00001	C		
Link FPC	312NIK24C1F	C		
Link FPC Gasket	56DNIK00007	C		

Designation	Part No.	RLC	Part	Location
Link FPC Gasket B	56DNIK00006	C		
Loudspeaker	F79124032000	C		
Main Camera 5M	475NIK0210A	B		
Microphone Mesh	56ANIK00003	C		
Microphone Rubber	455NIK0410A	C		
2 nd Microphone Rubber	455NIK0110A	C		
<u>Rear Cover</u> Rear Cover DSDS Black	1272-3747	C		
Rear Cover SS Black	1272-3745			

Designation	Part No.	RLC	Part	Location
Reflective Sheet	460NIK00000	C		
RF Port Rubber	1272-4132	C		
Rubber Sensor	455NIK0310A	C		
Screw M1.4*2.4	500014024Z1	C		
Screw M1.6*4.0	500016040Z1	C		
Screw M1.6*3.0	500016030Z1	C		
SIM Board Adhesive	56BNIK00000	C		
<u>SIM Board</u> SIM Board DSDS	311NIK2602E	C		

Designation	Part No.	RLC	Part	Location
SIM Board SS	311NIK2603E			
Speaker Gasket	56DNIK00001	C		
<u>Speaker Mesh</u> Speaker Mesh Black Speaker Mesh White	1272-3818 1272-3819	C		
Speaker Mesh on Rear Cover	455NIK0810A	C		
Speaker Sponge	56DNIK00004	C		
Touch Panel Adhesive	56BNIK00004	C		
<u>Touch Panel</u> Touch Panel Black Touch Panel White	35031021Z00 35031020Z00	B		
Water Indicator	1221-5956	C		

Designation	Part No.	RLC	Part	Location
<u>Volume Key</u> Volume Key Black Volume Key White	1272-3810 1272-3811	C		

2 Revision History

Rev.	Date	Changes / Comments
1	2013-Aug-09	Initial release
2	2013-Aug-09	Update DSDS info
3	2013-Sep-25	Update DSDS info and add new part Kapton Tape Display FPC
4	2013-Nov-26	Update RLC content