

Repair Movies

- mechanical -



Xperia™ ZL
C6502, C6503, C6506 & L35h

CONTENTS

| | | |
|--|-------------------------------|----------|
| 1 | Movies | 3 |
| 1.1 | Disassembly | 3 |
| Movies Error! Bookmark not defined. | | |
| 1.2 | Reassembly | 4 |
| 2 | Revision History | 5 |

To view the embedded repair movies in this document, Acrobat Reader version 8 (or later) and Flash Player version 8 (or later) must be installed on your computer.

***For best picture quality, select “Actual size” or “100%” as zoom level in Acrobat Reader.
To magnify while keeping an acceptable picture quality, increase the zoom level to 200%.***

***If the movies appear to be jerky or blurred when viewing on-line, this is probably caused by the connection speed being too slow.
In that case, right-click with the mouse on the document name and select Save Target As to download the repair movie document for off-line viewing.***

***For general information about repair movies, refer to
1220-1333: Generic Repair Manual - mechanical***

1 Movies

1.1 Disassembly

The Disassembly is done to the following modules:

1. Back Cover Assy
2. Clip USB
3. Carrier Spbox Assy
4. PBA Complete Assy
5. Front Assy Unit
6. NFC Antenna



Movies

1.2 Reassembly

The Disassembly is done to the following modules:

1. Ant NFC
2. Front Assy Unit
3. PBA Complete Assy
4. Carrier Spbox Assy
5. Clip USB
6. Back Cover Assy



2 Revision History

| Rev. | Date | Changes / Comments |
|------|-------------|--------------------|
| 1 | 2013-Feb-27 | Initial release |