


# Repair Movies

- mechanical -



*Xperia M2™ Aqua*  
*D2403, D2406*

## CONTENTS

<b>1</b>	<b>Movies .....</b>	<b>3</b>
1.1	Disassembly .....	3
1.2	Reassembly .....	3
<b>2</b>	<b>Revision History .....</b>	<b>4</b>

**To view the embedded repair movies in this document, Acrobat Reader version 8 (or later) and Flash Player version 8 (or later) must be installed on your computer.**

**For best picture quality, select “Actual size” or “100%” as zoom level in Acrobat Reader.  
To magnify while keeping an acceptable picture quality, increase the zoom level to 200%.**

**If the movies appear to be jerky or blurred when viewing on-line, this is probably caused by the connection speed being too slow.**


**In that case, right-click with the mouse on the document name and select Save Target As to download the repair movie document for off-line viewing.**

**For general information about repair movies, refer to  
1220-1333: Generic Repair Manual - mechanical**

## 1 Movies


### 1.1 Disassembly

1. Battery Cover Assy
2. Embedded Battery Assy
3. Main ANT Assy
4. Sub Board Assy
5. Main PBA
6. Front Cover LCM TP Assy



### 1.2 Reassembly

1. Front Cover LCM TP Assy
2. Main PBA
3. Sub Board Assy
4. Main ANT Assy
5. Embedded Battery Assy
6. Battery Cover Assy



## 2 Revision History

Rev.	Date	Changes / Comments
1	2014-07-16	Initial release