

## Part List

- mechanical -



*Xperia™ Z5 Compact*  
*E5803, E5823*



Part List Mechanical/

**CONTENTS**

1 Part List ..... 3

2 Revision History ..... 11

## 1 Part List

















The following parts are available for order in 'E-star'.

The 'E-star' name of a part may often be complex and even confusing, so the name of certain parts mentioned in the Working Instructions, Repair Movies and Troubleshooting Guide are often referred to by a simple descriptive name for better understanding.

















Both names (designations) will in that case be included in this Part List, where the name being used in the documents mentioned above is underlined, e.g. Battery Cover.

RLC, Reversed Logistic Classification column for replaced part handling, See the Spare part handling chapter in Mechanical/Generic Repair Manual (1220-1333).

Designation	Part No.	RLC	Part	Location
Adhesive Double Side FP Sensor	1294-9806	C		
Adhesive Double Side Ring FP Sensor	1294-9807	C		
Ant Main Flex Gina	1294-6970	C		
<u>Battery</u> Battery E58 2700.0 mAh embedded	1293-8715	C		
<u>Cap SIM/SD</u> Cap SIM/SD Sub Assy Black Cap SIM/SD Sub Assy Coral Cap SIM/SD Sub Assy White Cap SIM/SD Sub Assy Yellow	1294-9916 1295-5104 1295-4888 1295-4900	C		
Carrier Holder Chat Camera	1294-9861	C		

Designation	Part No.	RLC	Part	Location
Carrier Holder Guide USB Black	1294-9788	C		
Carrier Holder Key	1294-9828	C		
Carrier Holder NFC Antenna	1294-9866	C		
Carrier Holder Strap Black	1294-9785	C		
Cover Rear Sub Assy	1294-9867	C		
Cushion 0.0 mmSpeaker Bottom	1294-9872	C		
Cushion ACO Spacer JK FPC	1294-9860	C		
<u>Chat Camera</u> FICTIVE Chat Camera 5 MP	1293-7679	C		

Designation	Part No.	RLC	Part	Location
<u>Main Camera</u> FICTIVE Main Camera 24.5 MP	1294-0715	B		
Fingerprint sensor assy	1297-3730	B		
Foil Adhesive Double Side 0.0 mmFlash FP	1294-9873	C		
Foil Adhesive Double Side Battery	1294-9865	C		
Foil Adhesive Double Side ZIF Connector	1294-9855	C		
Foil Adhesive Key FPC	1294-9625	C		
Foil Adhesive Proximity Sensor	1294-9626	C		
Foil Adhesive RF Conductive Key FPC Bottom	1294-9774	C		
















Designation	Part No.	RLC	Part	Location
Foil Adhesive RF Conductive Key FPC Top	1294-9772	C		
Foil Adhesive Vib	1294-9630	C		
Foil Adhesive WR Panel Back	1294-9914	C		
Foil WR Speaker	1294-9862	C		
<u>FPC Assembly Bottom</u> FPC Assembly Bottom FLEX module	1293-7578	C		
<u>FPC Assembly Flash</u> FPC Assembly Flash FLEX module	1293-7584	C		
<u>FPC Assembly JK</u> FPC Assembly JK FLEX module	1293-7587	C		
<u>FPC Assembly Key</u> FPC Assembly Key FLEX module	1293-7591	C		

Designation	Part No.	RLC	Part	Location
FPC Assembly NFC antenna	1294-5558	C		
<u>FPC Assembly USB</u> FPC Assembly USB FLEX module	1293-7601	C		
<u>Front Assy</u> Front Assy Black Front Assy Coral Front Assy White Front Assy Yellow	1297-3728 1297-3734 1297-3732 1297-3733	A		
Holder Vibrator	1282-2268	C		
<u>Key Camera</u> Key Camera Black Key Camera Coral Key Camera White Key Camera Yellow	1294-9791 1295-5092 1295-4873 1295-4896	C		
<u>Key Volume</u> Key Volume Black Key Volume Coral Key Volume White Key Volume Yellow	1294-9790 1295-5091 1295-4863 1295-4894	C		
Label 0.0 mm x 0.0 mm	1294-9921	C		
Liquid indicator	1275-3307	C		


















# SONY

## Part List Mechanical/

Designation	Part No.	RLC	Part	Location
Loudspeaker + Ear Speaker 16.0 Rectangular	1293-4658	C		
Mic Sub Assy	1294-9825	C		
				
<u>Panel Back</u> Panel Back Sub Assy Black Panel Back Sub Assy Coral Panel Back Sub Assy White Panel Back Sub Assy Yellow	1294-9878 1295-5099 1295-4881 1295-4898	B		
<u>Ring FP Sensor</u> Ring FP Sensor Black Ring FP Sensor Coral Ring FP Sensor White Ring FP Sensor Yellow	1294-9794 1295-5094 1295-4877 1295-4897	C		
Screw M1.2*4.2	1294-9877	C		
Sheet ANT Spacer JK FPC	1294-9771	C		
Sheet Insulative DTV Tuner	1294-9853	C		



Designation	Part No.	RLC	Part	Location
Sheet Insulative NFC	1298-9815	C		
Sheet Main PBA Bottom	1296-8366	C		
Sheet SIM	1298-1556	C		
Sheet WR Mic	1294-9775	C		
				
Sheet WR Test	1294-9787	C		
Sheet ZIF Connector	1297-2146	C		
SIM Tray	1285-0492	C		

# SONY

Part List Mechanical/

Designation	Part No.	RLC	Part	Location
Speaker holder assy	1297-3731	B		
Tray Label	1294-9874	C		
WR Key Camera Sub Assy	1294-9822	C		
WR Key Volume Sub Assy	1294-9811	C		

## 2 Revision History

Rev.	Date	Changes / Comments
1	2015-Sep-07	Release