

# Part List

- mechanical -



**ST27i, ST27a**

**CONTENTS**

1 Part List ..... 3















2 Revision History ..... 7

## 1 Part List

















The following parts are available for order in 'E-star'.

The 'E-star' name of a part may often be complex and even confusing, so the name of certain parts mentioned in the Working Instructions, Repair Movies and Troubleshooting Guide are often referred to by a simple descriptive name for better understanding.

Both names (designations) will in that case be included in this Part List, where the name being used in the documents mentioned above is underlined, e.g. Battery Cover.

Designation	Part No.	Part	Location
<u>Audio Jack Cap</u> Audio Jack Cap Black Audio Jack Cap White Audio Jack Cap Yellow	1255-5227 1262-1947 1262-1948		
Audio Jack FPC	1255-7689		
<u>Back Housing Assy</u> Back Housing Assy Band125 Black Back Housing Assy Band18 Black Back Housing Assy Band18 White Back Housing Assy Band18 Yellow	1262-5150 1255-5039 1262-1909 1262-1910		
<u>Battery</u> Battery 1265.0 mAh (min capacity)	1255-9147		
Battery Adhesive	1262-2405		
<u>Battery Cover Assy</u> Battery Cover Assy White Battery Cover Assy Yellow Battery Cover Assy Black	1262-1956 1262-1958 1255-5117		
Bracket Proximity Sensor	1255-5554		

Designation	Part No.	Part	Location
Camera adhesive	1255-5161		
<u>Conn Audio Jack</u> Conn Audio Jack 6p	1256-0847		
Core Unit Label	1255-6377		
<u>Cover Front Housing Display Assy</u> Cover Front Housing Display Assy Black Cover Front Housing Display Assy White Cover Front Housing Display Assy Yellow	1264-8191 1264-8198 1264-8199		
<u>Ear Speaker</u> Ear Speaker 12.0 Rectangular Waterproof	1262-0804		
Key Sealing Gasket	1255-5630		
Key Sealing Gasket	1255-5630		
Key sealing Shading film for power key	1264-6686		

Designation	Part No.	Part	Location
Key sealing Shading film for volume key	1264-6687		
Liquid Indicator	1001-0084		
<u>Main Camera</u> Camera 5 MPixel CMOS	1254-4913		
Main O Ring	1255-5638		
Micro SD Cover	1255-5057		
<u>Micro USB Cap</u> Micro USB Cap Black Micro USB Cap White Micro USB Cap Yellow	1255-5221 1262-1940 1262-1942		
Receiver Adhesive	1255-5246		
Receiver Film back side	1263-7911		

Designation	Part No.	Part	Location
Screw Other Len:0.0 Diam:1.4 water proof	1264-4018		
Screw Other Len:2.0 Diam:1.4	1256-3303		
Screw Other Len:3.5 Diam:1.7 selftap	1255-5565		
Screw Other Len:4.2 Diam:1.7 selftap	1261-7648		
Side slide type micro-SIM adapter	1263-6090		
SIM Drawer	1255-5243		
Vibrator Main Mic Volume key FPC	1255-7685		

## 2 Revision History

Rev.	Date	Changes / Comments
1	2012-Jun-25	Initial release
2	2012-Jun-27	No update