

Part List, Mechanical

Applicable for Z770i

CONTENTS

1	General	2
2	Parts.....	3
	2.1 Upper Section	3
	2.2 Lower Section	10
3	Label Part List.....	19
4	Revision History	20



1 General





This Part List includes all parts possible to replace by using the Mechanical Repair Process.
Parts available to order will be found in the Web Shop.



The hinge of this phone is used as a dividing point to separate the phone into two identifiable sections. The section of the phone that contains the keypad will be referred as the lower section of the phone. The section of the phone that contains the displays will be referred as the upper section of the phone. This document is structured based on these two distinct sections.



2 Parts









2.1 Upper Section









Part	Part Location on Phone	Working Instruction Description	Webshop Description	Part Number	Comments
		CS unique Z770i upper inner cover assy.	Z770i upper inner cover assy. black	1205-3989	
			Z770i upper inner cover assy. red	1205-4006	
			Z770i upper inner cover assy. gold	1206-2994	









Part	Part Location on Phone	Working Instruction Description	Webshop Description	Part Number	Comments
		CS unique Z770i upper outer cover assy.	Z770i upper outer cover assy. black	1205-4013	
			Z770i upper outer cover assy. red	1205-4017	
			Z770i upper outer cover assy. Gold	1206-2996	
			Z770i upper outer Cover Assy, Black/DUCATI	1212-2394	
		Inner stopper	Inner stopper, silver Inner stopper, black	1203-3888 1201-7903	

Part	Part Location on Phone	Working Instruction Description	Webshop Description	Part Number	Comments
		Co brand inner	Co brand inner, black/generic (Z770i)	1201-7902	
			Co brand inner, silver/generic (Z770i)	1203-3763	
			Co brand inner, black/Telefonica	1205-7346	
			Co brand inner, silver/Telefonica	1205-7350	
			Co brand inner, black/TIM	1205-7347	
			Co brand inner, silver/TIM	1205-7351	
			Co brand inner, black/Hutch	1207-4111	
			Co brand inner, silver/Hutch	1207-4115	
			Co brand inner, Silver/DUCATI	1211-3878	







Part	Part Location on Phone	Working Instruction Description	Webshop Description	Part Number	Comments
		Co brand outer	Co brand outer, back/generic (Z770i)	1201-7904	
			Co brand outer, silver/generic (Z770i)	1203-3890	
			Co brand outer, black/Telefonica	1205-7354	
			Co brand outer, silver/Telefonica	1205-7358	
			Co brand outer, black/TIM	1205-7355	
			Co brand outer, silver/TIM	1205-7359	
			Co brand outer, black/Hutch	1207-4106	
			Co brand outer, silver/Hutch	1207-4108	
			Co brand Outer, Black/DUCATI	1211-3901	









Part	Part Location on Phone	Working Instruction Description	Webshop Description	Part Number	Comments
		Camera 2 M pixel	Camera 2 M pixel	1201-8542	
		Display 2.2 TFT	Display 2.2 TFT	1202-0319	
		Magnet	Magnet	SXA1096703	1002-0015
		Gasket 70 pin	Gasket 70 pin	1202-1148	



Part	Part Location on Phone	Working Instruction Description	Webshop Description	Part Number	Comments
		Main hinge FPC	Main hinge FPC	1201-3998	
		Gasket hinge	Gasket hinge	1203-3704	
					
					

Part	Part Location on Phone	Working Instruction Description	Webshop Description	Part Number	Comments
		Screw 2.5 x 1.6	Screw 2.5 x 1.6	1201-7882	
		Screw 3.5 x 1.6	Screw 3.5 x 1.6	1201-7884	
		Liquid intrusion indicator	Liquid intrusion indicator	SXA1094884	1001-0084
					

2.2 Lower Section







Part	Part Location on Phone	Working Instruction Description	Webshop Description	Part Number	Comments
		M2 card cap	M2 card cap, silver M2 card cap, black	1203-3673 1201-7868	
		Battery cover	Battery cover, silver Battery cover, black Battery cover, black/DUCATI Motorbike Battery cover, black/DUCATI	1203-3650 1201-7867 1212-1289 1211-3899	
		Lower outer SE logo	Lower outer SE logo, silver Lower outer SE logo, black Lower outer SE Logo, Black/DUCATI	1203-3891 1201-7869 1211-3935	









Part	Part Location on Phone	Working Instruction Description	Webshop Description	Part Number	Comments
		Left lower outer screw cap	Left lower outer screw cap, silver Left lower outer screw cap, black	1203-3645 1201-7923	
		Right lower outer screw cap	Right lower outer screw cap, silver Right lower outer screw cap, black	1203-3647 1201-8385	
		Icon 5.5	Icon 5.5	SXA1093000/1	1200-0691
		KRH label	KRH label	1202-5662	









Part	Part Location on Phone	Working Instruction Description	Webshop Description	Part Number	Comments
		Keypad	Keypad Latin, black	1201-7861	The "Black,Gold,Red" description is referring to the color of the phone not the part.
			Keypad Bopomofo, black	1205-7313	
			Keypad Thai, black	1205-7322	
			Keypad Arabic, black	1205-7329	
			Keypad Cyrillic, black	1205-3590	
			Keypad Latin, gold	1203-3652	
			Keypad Bopomofo, gold	1205-7317	
			Keypad Thai, gold	1205-7324	
			Keypad Arabic, gold	1205-7328	



















Part	Part Location on Phone	Working Instruction Description	Webshop Description	Part Number	Comments
			Keypad Cyrillic, gold	1205-3594	
			Keypad Latin, red	1204-2453	
			Keypad Bopomofo, red	1205-7319	
			Keypad Thai, red	1205-7326	
			Keypad Arabic, red	1205-7327	
			Keypad Cyrillic, red	1205-3597	
			keypad Arabic Red	1221-6627	
			keypad Arabic Black	1205-7329	

Part	Part Location on Phone	Working Instruction Description	Webshop Description	Part Number	Comments
		Lower inner assembly	Lower inner assembly, black	1201-7874	
			Lower inner assembly, red	1204-1548	
			Lower inner assembly, gold	1203-3630	
		Metal strap	Metal strap	1201-7878	
		Film tape (strap)	Film tape (strap)	1203-3709	

Part	Part Location on Phone	Working Instruction Description	Webshop Description	Part Number	Comments
		Antenna sub PCBA	Antenna sub PCBA	1202-1515	
		Main keyboard FPC	Main keyboard FPC	1201-4000	
		Screw 2.5 x 1.6	Screw 2.5 x 1.6	1201-7882	
		Screw 3.5 x 1.6	Screw 3.5 x 1.6	1201-7884	

Part	Part Location on Phone	Working Instruction Description	Webshop Description	Part Number	Comments
		Screw 1.7 x 4.5	Screw 1.7 x 4.5	SXA1095884	1002-0035
		BB shield can lid	BB shield can lid	1201-4503	
		Lower outer assembly	Lower outer assembly, silver Lower outer assembly, black	1203-3632 1202-1407	Lower outer assembly already includes Main antenna Flex and Bluetooth antenna Flex(adhesived).
		Hinge clip	Hinge clip	1201-7888	

Part	Part Location on Phone	Working Instruction Description	Webshop Description	Part Number	Comments
		M2 reader black cushion tape	M2 reader black cushion tape	1202-1181	
		Gasket 22 pin	Gasket 22 pin	1202-1178	
		Gasket ESD 2 BB shielding can	Gasket ESD 2 BB shielding can	1202-1127	
		Volume key	Volume key	1201-7863	

Part	Part Location on Phone	Working Instruction Description	Webshop Description	Part Number	Comments
		Hinge	Hinge	1201-5021	
		Mic conductive rubber	Mic conductive rubber	1201-8052	
		Film on shielding	Film on shielding	1202-1183	
		M2 card	256MB M2 card 512MB M2 card	1001-1735 1001-1737	

3 Label Part List

Pos.	Description	Part Number	Comments
	KRH label	1202-5662	

4 Revision History

Rev.	Date	Changes / Comments
1	2008-03-20	First release
2	2008-05-22	Page 16, add comments about Lower outer assembly.
3	2008-6-10	Adding DUCATI parts: 1211-3878 co brand inner, Silver/DUCATI 1211-3901 co brand Outer, Black/DUCATI 1212-1289 Battery Cover, Black/DUCATI Motorbike 1211-3899 Battery Cover, Black/DUCATI 1211-3935 Lower outer SE Logo, Black/DUCATI 1212-2394 Upper outer Cover Assy, Black/DUCATI
4	2008-10-9	Adding comments for keypad on page 12.
5	2008-12-02	adding legacy p/n for the following SPACE ID: 1200-0691 icon ----- SXA1093000/1 1001-0084 Liquid Intrusion Indicator -- SXA1094884 1002-0035 Screw 1.7 x 4.5 ----- SXA1095884 1002-0015 Magnet ----- SXA1096703
6	2008-12-29	No changes.
7	2008-12-30	No changes.
8	2009-03-24	Adding following Arabic keypad 1221-6627, keypad Arabic Red 1205-7329, keypad Arabic Black
9	2009-03-26	No changes