


Repair Movies

- mechanical -



Xperia™ Z3 Tablet Compact
SGP611,SGP612,SGP621,SGP641

CONTENTS

1 Movies 3

1.1 Disassembly 3

1.2 Reassembly 4

2 Revision History 5

To view the embedded repair movies in this document, Acrobat Reader version 8 (or later) and Flash Player version 8 (or later) must be installed on your computer.

For best picture quality, select “Actual size” or “100%” as zoom level in Acrobat Reader. To magnify while keeping an acceptable picture quality, increase the zoom level to 200%.

If the movies appear to be jerky or blurred when viewing on-line, this is probably caused by the connection speed being too slow. In that case, right-click with the mouse on the document name and select Save Target As to download the repair movie document for off-line viewing.

For general information about repair movies, refer to 1220-1333: Generic Repair Manual - mechanical


1 Movies

1.1 Disassembly

SGP611, SGP612, SGP621, SGP641

The Disassembly is done to the following modules:

- Sim Tray nano
- Display
- Holder LCD FPC BTB
- Antenna WLAN
- RF Cable WLAN
- Sub PBA
- Plate USB
- Antenna Diversity
- Antenna Main
- Main Camera
- Chat Camera
- Vibrator
- Holder Vibrator
- FPC Top Flex module
- Sheet FPC Relay
- Frame Key
- Key Flex module
- Plate Screw
- Main PBA
- Battery




1.2 Reassembly

SGP611, SGP612, SGP621, SGP641

The Reassembly is done to the following modules:

- Battery
- Main PBA
- Plate Screw
- Key Flex module
- Frame Key
- Sheet FPC Relay
- FPC Top Flex module
- Holder Vibrator
- Vibrator
- Chat Camera
- Main Camera
- Antenna Main
- Antenna Diversity
- Plate USB
- Sub PBA
- RF Cable WLAN
- Antenna WLAN
- Holder LCD FPC BTB
- Display
- Sim Tray nano



2 Revision History

Rev.	Date	Changes / Comments
1	2014-10-15	Initial release