

# Part List

- mechanical -



*Xperia™ T2 Ultra Dual D5322, XM50h*  
*Xperia™ T2 Ultra D5303,D5306, XM50t*

## CONTENTS

<b>1</b>	<b>Part List .....</b>	<b>3</b>
<b>2</b>	<b>Revision History .....</b>	<b>10</b>













# 1 Part List















The following parts are available for order in 'E-star'.































The 'E-star' name of a part may often be complex and even confusing, so the name of certain parts mentioned in the Working Instructions, Repair Movies and Troubleshooting Guide are often referred to by a simple descriptive name for better understanding.

















Both names (designations) will in that case be included in this Part List, where the name being used in the documents mentioned above is underlined, e.g. Battery Cover.

RLC, Reversed Logistic Classification column for replaced part handling, See the Spare part handling chapter in Mechanical/Generic Repair Manual 1220-1333).









Designation	Part No.	RLC	Part	Location
Adhesive Audio Jack	1278-1622	C		
Adhesive Battery FPC	1278-0670	C		
Adhesive Main Ant PBA	1278-2339	C		
Adhesive Main FPC Single Side	1280-2800	C		
Adhesive Relay FPC Single Side	1278-3130	C		
(Only for XM 50t) Adhesive Sub Ant PBA (Ready W1413)	1278-2356	C		

Designation	Part No.	RLC	Part	Location
Adhesive Vibrator	1278-1621	C		
<u>Battery</u> Battery 3000mAh Assy	1281-7439	C		
<u>Battery Cover Assy</u> Cover Battery Assy Black Cover Battery Assy Black XM50t (Ready on W1413) Cover Battery Assy Purple Cover Battery Assy Purple XM50t (Ready on W1417) Cover Battery Assy White Cover Battery Assy White XM50t	1278-0718 1280-3390 1278-0721 1280-3393 1278-0720 1280-3392	C		
(Not valid for D5322 and XM50h) Bracket Assy Block 2nd SIM (Ready on W1413)	1278-0262	C		
<u>Bracket Assy Panel Key</u> Bracket Assy Panel Key Black Bracket Assy Panel Key Purple Bracket Assy Panel Key White	1278-0176 1278-0445 1278-0290	C		
<u>Bracket Assy Panel Right</u> Bracket Assy Panel Right Dual Black Bracket Assy Panel Right Dual Purple (Ready on W1414) Bracket Assy Panel Right Dual White Bracket Assy Panel Right Single Black Bracket Assy Panel Right Single Purple (Ready on W1417) Bracket Assy Panel Right Single White	1278-0170 1278-0443 1278-0287 1278-0167 1278-0440 1278-0283	C		
Cable antenna_cable	1278-2200	C		








Designation	Part No.	RLC	Part	Location
Camera 13 MPixel CMOS	1278-0255	C		
Camera Chat	1276-8890	C		
Camera Lens Adhesive	1278-1089	C		
<u>Cap SD</u> Cap Plastic Assy SD Black Cap Plastic Assy SD Purple (Ready on W1414) Cap Plastic Assy SD White	1278-0246 1278-0324 1278-0275	C		
(Only for D5322 and XM50h) <u>Cap SIM Dual</u> Cap Plastic Assy SIM Dual Black Cap Plastic Assy SIM Dual Purple (Ready on W1414) Cap Plastic Assy SIM Dual White	1278-0212 1278-0321 1278-0272	C		
(For D5303, D5306, XM50t) <u>Cap SIM Single</u> Cap Plastic Assy SIM Single Black Cap Plastic Assy SIM Single Purple (Ready on W1414) Cap Plastic Assy SIM Single White	1278-0206 1278-0316 1278-0269	C		
<u>Display Assy</u> Display Assembly Black D5303/D5306 (Ready on W1414) Display Assembly Black D5322/XM50h Display Assembly Black XM50t (Ready on W1413) Display Assembly Purple D5303/D5306 (Ready on W1414) Display Assembly Purple D5322/XM50h (Ready on W1414) Display Assembly Purple XM50t (Ready on W1417) Display Assembly White D5303/D5306 Display Assembly White D5322/XM50h Display Assembly White XM50t	1281-7414 1281-7388 1285-7155 1281-7417 1281-7399 1285-7148 1281-7427 1281-7395 1285-7153	A	        	        

Designation	Part No.	RLC	Part	Location
Earspeaker	1244-5343	C		
Flash Lens	1278-1109	C		
Flash Lens Adhesive	1278-1107	C		
Foil 0.0 mm CU label Tray	1278-0689	C		
Foil 0.0 mm Battery Right	1278-1619	C		
FPC Audio Jack	1277-0817	C		
<u>FPC Relay</u> FPC Relay D5322/XM50h/D5303/D5306/XM50t	1277-0807	B		
<u>FPC SIM</u> FPC Dual SIM D5322/XM50h	1277-0814	C		

Designation	Part No.	RLC	Part	Location
FPC Single SIM (Ready on W1413)	1277-0809	C		
Gasket Conductive Relay FPC Speaker	1278-2112	C		
Gasket Conductive Relay FPC Vib Gasket	1278-2118	C		
Gasket Receiver	1278-1623	C		
Gasket Speaker	1278-1012	C		
<u>Key Camera</u> Key Camera Assy Black Key Camera Assy Purple (Ready on W1414) Key Camera Assy White	1278-0075 1278-0313 1278-0102	C		
<u>Key On/Off</u> Key On/Off Assy	1278-0062	C		
<u>Key Volume</u> Key Volume Assy Black Key Volume Assy Purple (Ready on W1414) Key Volume Assy White	1278-0070 1278-0311 1278-0105	C		

Designation	Part No.	RLC	Part	Location
<u>Label</u> Label D53 15.3 mm x 13.1 mm Label D53 15.3 mm x 13.1 mm XM50t (Ready on W1413)	1278-2842 1280-2934	C		
<u>Loudspeaker</u> Loudspeaker D5303/D5306 (Ready on W1414) Loudspeaker D5322/XM50h/XM50t	1274-9716 1274-9919	C		
Main Camera Ring	1278-1106	C		
Main Camera Ring Adhesive	1278-1099	C		
MComp Assy Ring Power	1278-0069	C		
(Only for XM50t) PBA 2nd Main Antenna XM50t (Ready on W1413)	1277-5377	C		
<u>PBA Main Antenna</u> PBA Main Antenna D5303/D5306 (Ready on W1414) PBA Main Antenna D5322/XM50h PBA Main Antenna XM50t (Ready on W1413)	1278-1556 1277-5375 1278-1557	C		
<u>Rear Cover Assy</u> Rear Cover Assy Black D5303 (Ready on W1414) Rear Cover Assy Black D5306 (Ready on W1420) Rear Cover Assy Black D5322/XM50h Rear Cover Assy Black XM50t (Ready on W1413)	1278-1140 1278-1150 1278-1153 1278-1157	B		



Designation	Part No.	RLC	Part	Location
Screw 1.4X3.5	1262-1965	C		
Screw Other Len:0.0 Diam:0.0	1277-7492	C		
SIM Tray	1272-6336	C		
Speaker Mesh	1278-1018	C		
Vibrator	1264-2341	C		
Window Camera	1278-1091	C		

## 2 Revision History

Rev.	Date	Changes / Comments
1	2014-Mar-07	Initial release
2	2017-Mar-17	Update Loudspeaker 1274-9919 description by adding XM50h