



Part List

- mechanical -



Xperia™ X8

E15i, E15a, E16i, E16a



CONTENTS













1	Part List	3
2	Revision History	9

1 Part List

















The following parts are available for order in 'E-star'.















The 'E-star' name of a part may often be complex and even confusing, so the name of certain parts mentioned in the Working Instructions, Repair Movies and Troubleshooting Guide are often referred to by a simple descriptive name for better understanding.






Both names (designations) will in that case be included in this Part List, where the name being used in the documents mentioned above is underlined, e.g. Battery Cover.













Designation	Part No.	Part	Location
Adhesive Camera Window	1231-9755		
Adhesive Conductive Copper	1240-2683		
Adhesive FPC Display	1236-2887		
<u>Adhesive Loudspeaker</u> Gasket Speaker gasket upper	1248-0165		
Camera 3 MPixel	1230-6816		
<u>Cap USB</u> Cap USB Black Cap USB Walkman Black Cap USB White	1240-0768 1249-0978 1230-8927		

Designation	Part No.	Part	Location
Carrier LCM	1230-8938		
CCR-80 micro SD memory adapter, black	1226-9295		
<u>Co Brand</u> Co Brand Black Co Brand Black China Unicom Co Brand Black Movistar Co Brand Black Orange Co Brand White Quiksilver Co Brand White Roxy Co Brand Walkman Black Co Brand White Co Brand White China Unicom Co Brand White Movistar Co Brand White Orange	1241-0704 1242-7531 1242-7532 1242-7533 1252-4045 1252-4488 1249-1988 1241-0695 1242-3875 1242-3876 1242-3968		
<u>Cover Front assy</u> Cover Front assy Black Cover Front assy Walkman Black Cover Front assy White	1241-9399 1249-0075 1239-3969		
<u>Cover Rear</u> Cover Rear Black Cover Rear Black/Blue Cover Rear Black/Red Cover Rear Black/Silver Cover Rear Quiksilver Cover Rear Roxy Cover Rear Walkman Metallic Red Cover Rear Walkman Azur Cover Rear Walkman Orange Cover Rear White Cover Rear White/Aqua Cover Rear White/DarkBlue Cover Rear White/Pink Cover Rear White/Silver	1239-7527 1243-2862 1243-2863 1239-7525 1252-4044 1252-4487 1248-9454 1248-9455 1248-9456 1240-0429 1237-0351 1239-4362 1237-0350 1230-8891		

Designation	Part No.	Part	Location
Display 3.0 TFT	1235-2727		
Dome Sheet	1231-4253		
Earspeaker	1233-3960		
Front Key Activator	1231-7464		
Gasket Camera	1236-2608		
Gasket Conductive 3 x 4	1236-4284		
Gasket Conductive 3,8x2,3	1233-2177		
Gasket Loudspeaker	1233-0248		

Designation	Part No.	Part	Location
Grommet Mic	1230-8955		
HPM-60JS 3.5mm Stereo PHF	1241-1870		
<u>Inner Frame</u> Inner Frame 1/2/5 Inner Frame 1/8	1230-8944 1239-7033		
Keys Front	1230-8928		
Keys Side	1230-8898		
Label MicroSD	1236-2307		
Label Mobile Phone	1230-8964		
Liquid Indicator	1210-3726		

Designation	Part No.	Part	Location
Mesh Earspeaker	1236-4967		
MH810 Remote control headset Black	1231-6484		
<u>Micro SD</u> Micro SD 2Gb Micro SD 4Gb Micro SD 8Gb	1218-7894 1210-7834 1210-7835		
SAR Shield 1/2/5	1236-0527		
SAR Shield 1/8	1236-2533		
Screw Philips 2.2 x 1.4	1236-0069		
Screw Torx 5.5 x 1.6	1232-3427		
Shield Can Lid BB	1227-4450		

Designation	Part No.	Part	Location
Shield Can Lid LNA	1232-5741		
Shield Can Lid Radio	1227-4451		
Shield Can Lid WLAN	1227-4453		
Speaker	1231-5570		
Tape RF connector	1245-1127		
Window Camera	1230-8952		



2 Revision History

Rev.	Date	Changes / Comments
1	2010-Sept-27	Initial release
2	2010-Oct-29	Added parts for Black 1239-7527, 1240-0768, 1241-0704, 1241-9399, 1242-7531, 1242-7532 and 1242-7533
3	2011-Jan-26	Added 1239-7525, 1242-3968, 1243-2862 and 1243-2863
4	2011-May-16	Two new commercial models included - E16i and E16a Added parts for Walkman 1248-9454, 1248-9455, 1248-9456, 1249-0075, 1249-0978 and 1249-1988 1230-1224 is replaced by 1248-0165 Added 1245-1127
5	2011-June-23	Added parts for Quiksilver and Roxy 1252-4044, 1252-4045, 1252-4487 and 1252-4488