

SONY

make.believe

Repair Movies

- mechanical -



Xperia™ neo L

MT25i

CONTENTS

1 Movies 3

1.1 Disassembly 3

1.2 Reassembly 3

2 Revision History 4

To view the embedded repair movies in this document, Acrobat Reader version 8 (or later) and Flash Player version 8 (or later) must be installed on your computer.

For best picture quality, select “Actual size” or “100%” as zoom level in Acrobat Reader. To magnify while keeping an acceptable picture quality, increase the zoom level to 200%.

If the movies appear to be jerky or blurred when viewing on-line, this is probably caused by the connection speed being too slow. In that case, right-click with the mouse on the document name and select Save Target As to download the repair movie document for off-line viewing.

For general information about repair movies, refer to 1220-1333: Generic Repair Manual - mechanical

1 Movies

1.1 Disassembly

1. Battery Cover
2. Battery
3. Rear Cover Assembly
4. Sub SIM PBA Assy
5. Front Cover Assy
6. Cushion LCD Shim Black
7. Display
8. Main PBA (a) & LCD Frame (b)



1.2 Reassembly

1. Main PBA (a) & LCD Frame (b)
2. Display
3. Cushion LCD Shim Black
4. Front Cover Assy
5. Sub SIM PBA Assy
6. Rear Cover Assembly
7. Battery Cover
8. Battery



2 Revision History

Rev.	Date	Changes / Comments
1	2012-Jun-25	Initial release