



INSTALLATION GUIDE

NOKIA WIRELESS PRESENTER

NOKIA



Contents

- 1. HARDWARE AND SOFTWARE REQUIREMENTS.....2
- 2. INSTALLING NOKIA WIRELESS PRESENTER.....3
 - 2.1 INSTALLING NOKIA WIRELESS PRESENTER ON WINDOWS.....3
 - 2.2 INSTALLING NOKIA WIRELESS PRESENTER ON NOKIA SERIES 60 MOBILE PHONE.....3
- 3. TECHNICAL SUPPORT.....4

**Legal Notice**

Copyright © 2002 Nokia. All rights reserved.

Reproduction, transfer, distribution or storage of part or all of the contents in this document in any form without the prior written permission of Nokia is prohibited.

Nokia and Nokia Connecting People are registered trademarks of Nokia Corporation. Other product and company names mentioned herein may be trademarks or tradenames of their respective owners.

Nokia operates a policy of continuous development. Nokia reserves the right to make changes and improvements to any of the products described in this document without prior notice.

Under no circumstances shall Nokia be responsible for any loss of data or income or any special, incidental, consequential or indirect damages howsoever caused.

The contents of this document are provided "as is". Except as required by applicable law, no warranties of any kind, either express or implied, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose, are made in relation to the accuracy, reliability or contents of this document. Nokia reserves the right to revise this document or withdraw it at any time without prior notice.



1. HARDWARE AND SOFTWARE REQUIREMENTS

You need the following hardware and software to use Nokia Wireless Presenter.

- A PC with a Windows 98, Windows ME, Windows XP or Windows 2000 operating system.
- A Nokia Series 60 mobile phone.
- A Bluetooth (version 1.1 or greater) compatible device providing a virtual serial port.
- 10 MB of free hard disk space.

The following Bluetooth devices have been tested to be compatible with Nokia Wireless Presenter:

- Nokia Connectivity Card DTL-4
- Toshiba Bluetooth PC Card PA3053E
- Toshiba Portégé 4010 integrated Bluetooth
- IBM Bluetooth UltraPort Module (with USB adaptor)
- Widcomm Bluetooth USB adaptor
- 3COM Bluetooth PC Card 3CRWB6096
- Socket Bluetooth Connection Kit
- Anycom Bluetooth PC Card
- Billionton Bluetooth USB adapter
- TDK Bluetooth PC Card
- TDK Bluetooth USB adaptor
- ComOne Bluetooth USB
- ComOne Bluetooth PCMCIA

The following Bluetooth devices have been tested with Nokia Wireless Presenter and problems have been found:

- Brainboxes Bluetooth USB Adaptor

2. INSTALLING NOKIA WIRELESS PRESENTER

This chapter guides you through the installation of Nokia Wireless Presenter on Windows and on a Nokia mobile phone.

2.1 INSTALLING NOKIA WIRELESS PRESENTER ON WINDOWS

1. Start **Setup.exe**, which you received as part of the Nokia Wireless Presenter setup package.
2. Follow the instructions given by the setup program.
3. Use the Bluetooth supplier's configuration tool to find out which virtual serial port is configured to use the serial port profile. For more information, see the Bluetooth device's documentation.
4. Start **Nokia Wireless Presenter** on the PC (for example, Start->Programs->Nokia Wireless Presenter->Nokia Wireless Presenter).
5. Configure Nokia Wireless Presenter to use the proper serial port (which was found in step 3). This can be done with the "Configure Nokia Wireless Presenter" window. See the Nokia Wireless Presenter help file for more information.

2.2 INSTALLING NOKIA WIRELESS PRESENTER ON NOKIA SERIES 60 MOBILE PHONE

The Nokia Wireless Presenter software can be installed on a Nokia phone via an infrared or a Bluetooth connection. To install Nokia Wireless Presenter on the Nokia phone via infrared:

1. Start infrared reception on a Nokia phone and place it near the PC's infrared port.
2. Open the **Phone Software** folder by left-clicking on the folder name in Windows' Start menu (for example, Start->Programs->Nokia Wireless Presenter->Phone Software).
3. Right-click on "**Wireless Presenter.sis**" in the Phone Software folder and select **Send To: Infrared Recipient**.
4. Nokia Wireless Presenter is now in the inbox of your Nokia phone and can be opened from there. For more information, consult the mobile phone's User Guide.



Tip: For Nokia PC Suite users: make sure PC Suite is online and double-click on "Wireless Presenter.sis" in step 3.



To install Nokia Wireless Presenter on a Nokia phone via Bluetooth:

1. Open the **Phone Software** folder by left-clicking on the folder name in Windows' Start menu (for example, Start->Programs->Nokia Wireless Presenter->Phone Software).
2. Check how to transfer files from PC to other Bluetooth devices in your Bluetooth device's manual and send "**Wireless Presenter.sis**" file to the phone over Bluetooth.
3. Nokia Wireless Presenter is now in the inbox of your Nokia phone and can be opened from there. For more information, consult the mobile phone's User Guide.



Note: Nokia PC Suite may reserve the Bluetooth virtual serial port. To use Nokia Wireless Presenter on the same computer you may need to release the port from Nokia PC Suite first.

3. TECHNICAL SUPPORT

Technical support is available from nwp.support@nokia.com