



Go/No Go Test Script Specification, Electrical

Applicable for W710 and Z710

Contents

1 ... General	3
1.1 About This Document	3
1.2 Script Requirements	3
1.3 Channel Allocation Table	4
1.4 Power Level Allocation Table	4
1.5 Test Limits	4
2 ... Test Sequence using an RF Shield Box and Coupler	5
2.1 Initializing and Call Setup	5
2.2 Audio Loopback	6
2.3 Measurement Group ALLMEAS LCH 850	6
2.4 Measurement Group ALLMEAS MCH 850	6
2.5 Measurement Group ALLMEAS HCH 850	7
2.6 Measurement Group ALLMEAS LCH 1900	7
2.7 Measurement Group ALLMEAS MCH 1900	8
2.8 Measurement Group ALLMEAS HCH 1900	8
2.9 Measurement Group ALLMEAS LCH 900	9
2.10 Measurement Group ALLMEAS MCH 900	9
2.11 Measurement Group ALLMEAS HCH 900	10
2.12 Measurement Group ALLMEAS LCH 1800	10
2.13 Measurement Group ALLMEAS MCH 1800	11
2.14 Measurement Group ALLMEAS HCH 1800	11
3 ... Test Sequence using a Direct Line Connection	12
3.1 Initializing and Call Setup	12
3.2 Audio Loopback	13
3.3 Measurement Group ALLMEAS LCH 850	13
3.4 Measurement Group ALLMEAS MCH 850	13
3.5 Measurement Group ALLMEAS HCH 850	14
3.6 Measurement Group ALLMEAS LCH 1900	14
3.7 Measurement Group ALLMEAS MCH 1900	15
3.8 Measurement Group ALLMEAS HCH 1900	15
3.9 Measurement Group ALLMEAS LCH 900	16
3.10 Measurement Group ALLMEAS MCH 900	16
3.11 Measurement Group ALLMEAS HCH 900	17
3.12 Measurement Group ALLMEAS LCH 1800	17
3.13 Measurement Group ALLMEAS MCH 1800	18
3.14 Measurement Group ALLMEAS HCH 1800	18



4... Attenuation Factors	19
4.1 W710 in the Rohde & Schwarz RF Shield Box and Coupler.....	19
4.2 Z710 in the Rohde & Schwarz RF Shield Box and Coupler	20
4.3 W710 and Z710 with the RF fixture (Conducted).....	21
5... Revision History	21



1 General

1.1 About This Document

This document contains the test requirements for an EDGE quad-band (850/900/1800/1900) pocket transceiver for use with an antenna coupler or direct line connection. These test sequences should be used as an arrival and verification test of radio functionality.

Tests are done in signaling mode, i.e. a call has been established to the test instrument. The test instrument controls the transceiver unit. RF performance is measured with an antenna coupler (radiated) or the direct line connection (conducted), whichever method is selected.

1.2 Script Requirements

- The test should be designed so those users with little or no system expertise can perform accurate testing.
- The measurements should run automatically, though a certain amount of manual work is included (and mandatory), such as MS call setup (i.e. dialing number).
- It should be possible to print or store the measurement results.
- It should be possible to change the channels used in testing due to possible local radio interference. The ranges for these settings are specified under the *Channel Allocation Table*.
- All functions and settings should be protected in such a manner that the end-user cannot directly change them. (For example, a password or encrypted settings file.)
- The attenuation factors that should be used are stated in section 4. The test instrument must be capable of using different attenuation factors for RX and TX. It must also be possible to use various attenuation factors for different channels in each band.

NOTE! **Any setups other than the one stated in this document must be discussed and approved by Sony Ericsson.**

1.3 Channel Allocation Table

Band	Ch definition	Any ARFCN of:
GSM850	Low	128-132
GSM850	Mid	187-191
GSM850	High	247-251
GSM900	Low	975-979
GSM900	Mid	36-40
GSM900	High	120-124
GSM 1800	Low	512-517
GSM 1800	Mid	697-702
GSM 1800	High	880-885
GSM1900	Low	512-517
GSM1900	Mid	658-663
GSM1900	High	805-810

1.4 Power Level Allocation Table

Band	PL definition	Powerlevel (PL)
GSM850/900	Lowest	19
GSM850/900	Mid	12
GSM850/900	Highest	7
GSM1800/1900	Lowest	15
GSM1800/1900	Mid	8
GSM1800/1900	Highest	0

1.5 Test Limits

The test limits for each measurement are specified in the Sequence Tables.

1. Since the coupler introduces higher measurement inaccuracy, some measurements may have wider limits than stated in the GSM specifications.
2. The direct line connection limits conform to the phase 2 GSM specification.



2 Test Sequence using an RF Shield Box and Coupler

2.1 Initializing and Call Setup

Parameter	Value	Unit
BCCH	Mid	Ch
TCH	Low	Ch
TX power level	High	PL
RF output power	-40	dBm
System	GSM 1900	

2.1.1 Sequence

1. Initialize instrument
2. Insert a test-SIM and attach a fully charged standard battery to the mobile. It's very important that a fully charged battery is used otherwise there is a high risk for incorrect test results.
3. Position the mobile in the coupler according to the picture.



Rohde & Schwarz Shield Box and Coupler

4. Turn on the mobile and wait for registration.
5. Set up a call to the instrument or let the instrument call the mobile.
6. Close the lid on the shielding box.



2.2 Audio Loopback

1. Set power level to high.
2. Activate audio loopback in the instrument.
3. Operator must acknowledge passed or failed before the test is continued.

2.3 Measurement Group ALLMEAS LCH 850

Parameter	Value	Unit
TCH	Low	Ch
TX power level	High	PL
RF output power	-68	dBm
System	GSM 850	

2.3.1 Sequence

Measurement	Test Limits	Unit
TX power	29 +/-4	dB
RMS Phase error	0 +/-5	deg
Rx Level	34-50	dB
Rx Quality	0-3	Units

2.4 Measurement Group ALLMEAS MCH 850

Parameter	Value	Unit
TCH	Mid	Ch
TX power level	Mid	PL
RF output power	-102	dBm
System	GSM 850	

2.4.1 Sequence

Measurement	Test Limits	Unit
TX power	19 +/-5	dB
RMS Phase error	0 +/-5	deg
Peak Phase error	0 +/-20	deg
Freq error	+/-0.1 ppm	Hz
Rx Level	2-14	dB
Rx Quality	0-3	Units



2.5 Measurement Group ALLMEAS HCH 850

Parameter	Value	Unit
TCH	High	Ch
TX power level	Low	PL
RF output power	-68	dBm
System	GSM 850	

2.5.1 Sequence

Measurement	Test Limits	Unit
TX power	5 +/-7	dB
RMS Phase error	0 +/-5	deg

2.6 Measurement Group ALLMEAS LCH 1900

Parameter	Value	Unit
TCH	Low	Ch
TX power level	Low	PL
RF output power	-68	dBm
System	GSM 1900	

2.6.1 Sequence

Measurement	Test Limits	Unit
TX power	0 +/-7	dB
RMS Phase Error	0 +/-5	deg
Rx Level	34-50	dB
RX Quality	0-3	Units



2.7 Measurement Group ALLMEAS MCH 1900

Parameter	Value	Unit
TCH	Mid	Ch
TX power level	Mid	PL
RF output power	-102	dBm
System	GSM 1900	

2.7.1 Sequence

Measurement	Test Limits	Unit
TX power	14 +/-5	dB
RMS Phase error	0 +/-5	deg
Peak Phase error	0 +/-20	deg
Freq. error	+/-0.1 ppm	Hz
Rx Level	2-14	dB
Rx Quality	0-3	Units

2.8 Measurement Group ALLMEAS HCH 1900

Parameter	Value	Unit
TCH	High	Ch
TX power level	High	PL
RF output power	-68	dBm
System	GSM 1900	

2.8.1 Sequence

Measurement	Test Limits	Unit
TX power	30 +/-4	dB
RMS Phase error	0 +/-5	deg



2.9 Measurement Group ALLMEAS LCH 900

Parameter	Value	Unit
TCH	Low	Ch
TX power level	High	PL
RF output power	-68	dBm
System	GSM 900	

2.9.1 Sequence

Measurement	Test Limits	Unit
TX power	33 +/-4	dB
RMS Phase error	0 +/-5	deg
Rx Level	34-50	dB
Rx Quality	0-3	Units

2.10 Measurement Group ALLMEAS MCH 900

Parameter	Value	Unit
TCH	Mid	Ch
TX power level	Mid	PL
RF output power	-102	dBm
System	GSM 900	

2.10.1 Sequence

Measurement	Test Limits	Unit
TX power	19 +/-5	dB
RMS Phase error	0 +/-5	deg
Peak Phase error	0 +/-20	deg
Freq error	+/-0.1 ppm	Hz
Rx Level	2-14	dB
Rx Quality	0-3	Units



2.11 Measurement Group ALLMEAS HCH 900

Parameter	Value	Unit
TCH	High	Ch
TX power level	Low	PL
RF output power	-68	dBm
System	GSM 900	

2.11.1 Sequence

Measurement	Test Limits	Unit
TX power	5 +/-7	dB
RMS Phase error	0 +/-5	deg

2.12 Measurement Group ALLMEAS LCH 1800

Parameter	Value	Unit
TCH	Low	Ch
TX power level	High	PL
RF output power	-68	dBm
System	GSM 1800	

2.12.1 Sequence

Measurement	Test Limits	Unit
TX power	30 +/-4	dB
RMS Phase Error	0 +/-5	deg
Rx Level	34-50	dB
RX Quality	0-3	Units



2.13 Measurement Group ALLMEAS MCH 1800

Parameter	Value	Unit
TCH	Mid	Ch
TX power level	Mid	PL
RF output power	-102	dBm
System	GSM 1800	

2.13.1 Sequence

Measurement	Test Limits	Unit
TX power	14 +/-5	dB
RMS Phase error	0 +/-5	deg
Peak Phase error	0 +/-20	deg
Freq. error	+/-0.1 ppm	Hz
Rx Level	2-14	dB
Rx Quality	0-3	Units

2.14 Measurement Group ALLMEAS HCH 1800

Parameter	Value	Unit
TCH	High	Ch
TX power level	Low	PL
RF output power	-68	dBm
System	GSM 1800	

2.14.1 Sequence

Measurement	Test Limits	Unit
TX power	0 +/-7	dB
RMS Phase error	0 +/-5	deg

2.14.2 Call Disconnect Sequence

1. Disconnect call.
2. End test.




3 Test Sequence using a Direct Line Connection

3.1 Initializing and Call Setup

Parameter	Value	Unit
BCCH	Mid	Ch
TCH	Low	Ch
TX power level	High	PL
RF output power	-40	dBm
System	GSM 1900	

3.1.1 Sequence

1. Initialize instrument.
2. Insert a test-SIM and attach a fully charged standard battery to the mobile. It's very important that a fully charged battery is used otherwise there is a high risk for incorrect test results.
3. Remove the battery cover and connect the mobile to the RF Probe/Holder according to the picture.



4. Turn on the mobile and wait for registration.
5. Set up a call to the instrument or let the instrument call the mobile.



3.2 Audio Loopback

1. Set power level to high.
2. Activate audio loopback in the instrument.
3. Operator must acknowledge passed or failed before the test is continued.

3.3 Measurement Group ALLMEAS LCH 850

Parameter	Value	Unit
TCH	Low	Ch
TX power level	High	PL
RF output power	-68	dBm
System	GSM 850	

3.3.1 Sequence

Measurement	Test Limits	Unit
TX power	29 +/-2	dB
RMS Phase error	0 +/-5	deg
Rx Level	36-48	dB
Rx Quality	0-3	Units

3.4 Measurement Group ALLMEAS MCH 850

Parameter	Value	Unit
TCH	Mid	Ch
TX power level	Mid	PL
RF output power	-102	dBm
System	GSM 850	

3.4.1 Sequence

Measurement	Test Limits	Unit
TX power	19 +/-3	dB
RMS Phase error	0 +/-5	deg
Peak Phase error	0 +/-20	deg
Freq error	+/-0.1 ppm	Hz
Rx Level	4-12	dB
Rx Quality	0-3	Units



3.5 Measurement Group ALLMEAS HCH 850

Parameter	Value	Unit
TCH	High	Ch
TX power level	Low	PL
RF output power	-68	dBm
System	GSM 850	

3.5.1 Sequence

Measurement	Test Limits	Unit
TX power	5 +/-5	dB
RMS Phase error	0 +/-5	deg

3.6 Measurement Group ALLMEAS LCH 1900

Parameter	Value	Unit
TCH	Low	Ch
TX power level	Low	PL
RF output power	-68	dBm
System	GSM 1900	

3.6.1 Sequence

Measurement	Test Limits	Unit
TX power	0 +/-5	dB
RMS Phase error	0 +/-5	deg
Rx Level	36-48	dB
RX Quality	0-3	Units



3.7 Measurement Group ALLMEAS MCH 1900

Parameter	Value	Unit
TCH	Mid	Ch
TX power level	Mid	PL
RF output power	-102	dBm
System	GSM 1900	

3.7.1 Sequence

Measurement	Test Limits	Unit
TX power	14 +/-3	dB
RMS Phase error	0 +/-5	deg
Peak Phase error	0 +/-20	deg
Freq. error	+/-0.1 ppm	Hz
Rx Level	4-12	dB
Rx Quality	0-3	Units

3.8 Measurement Group ALLMEAS HCH 1900

Parameter	Value	Unit
TCH	High	Ch
TX power level	High	PL
RF output power	-68	dBm
System	GSM 1900	

3.8.1 Sequence

Measurement	Test Limits	Unit
TX power	30 +/-2	dB
RMS Phase error	0 +/-5	deg

3.9 Measurement Group ALLMEAS LCH 900

Parameter	Value	Unit
TCH	Low	Ch
TX power level	High	PL
RF output power	-68	dBm
System	GSM 900	

3.9.1 Sequence

Measurement	Test Limits	Unit
TX power	33 +/-2	dB
RMS Phase error	0 +/-5	deg
Rx Level	36-48	dB
Rx Quality	0-3	Units

3.10 Measurement Group ALLMEAS MCH 900

Parameter	Value	Unit
TCH	Mid	Ch
TX power level	Mid	PL
RF output power	-102	dBm
System	GSM 900	

3.10.1 Sequence

Measurement	Test Limits	Unit
TX power	19 +/-3	dB
RMS Phase error	0 +/-5	deg
Peak Phase error	0 +/-20	deg
Freq error	+/-0.1 ppm	Hz
Rx Level	4-12	dB
Rx Quality	0-3	Units



3.11 Measurement Group ALLMEAS HCH 900

Parameter	Value	Unit
TCH	High	Ch
TX power level	Low	PL
RF output power	-68	dBm
System	GSM 900	

3.11.1 Sequence

Measurement	Test Limits	Unit
TX power	5 +/-5	dB
RMS Phase error	0 +/-5	deg

3.12 Measurement Group ALLMEAS LCH 1800

Parameter	Value	Unit
TCH	Low	Ch
TX power level	High	PL
RF output power	-68	dBm
System	GSM 1800	

3.12.1 Sequence

Measurement	Test Limits	Unit
TX power	30 +/-2	dB
RMS Phase Error	0 +/-5	deg
Rx Level	36-48	dB
RX Quality	0-3	Units



3.13 Measurement Group ALLMEAS MCH 1800

Parameter	Value	Unit
TCH	Mid	Ch
TX power level	Mid	PL
RF output power	-102	dBm
System	GSM 1800	

3.13.1 Sequence

Measurement	Test Limits	Unit
TX power	14 +/-3	dB
RMS Phase error	0 +/-5	deg
Peak Phase error	0 +/-20	deg
Freq. error	+/-0.1 ppm	Hz
Rx Level	4-12	dB
Rx Quality	0-3	Units

3.14 Measurement Group ALLMEAS HCH 1800

Parameter	Value	Unit
TCH	High	Ch
TX power level	Low	PL
RF output power	-68	dBm
System	GSM 1800	

3.14.1 Sequence

Measurement	Test Limits	Unit
TX power	0 +/-5	dB
RMS Phase error	0 +/-5	deg

3.14.2 Call Disconnect Sequence

1. Disconnect call.
2. End test.

4 Attenuation Factors

4.1 W710 in the Rohde & Schwarz RF Shield Box and Coupler

The following values shall be used when testing the Sony Ericsson W710 in the Rohde & Schwarz RF shield box (**R&S part # 1150.1008.02**) using the Rohde & Schwarz coupler (**R&S part # 1150.0801.02**) and RF-cable (**SEMC part # RPM 119 855**). A precision type N Male to SMA Female adapter is required to connect the cable to the RF shield box.

Band	Channel*	Attenuation	
		RX	TX
GSM 850	Low	12.55	18.63
	Mid	11.30	17.85
	High	10.80	16.28
GSM 900	Low	10.80	11.32
	Mid	12.45	9.14
	High	14.00	9.44
GSM 1800	Low	9.90	13.05
	Mid	10.70	12.47
	High	11.65	11.09
GSM 1900	Low	15.15	11.11
	Mid	17.80	11.38
	High	21.50	13.91

* See Channel Allocation Table

4.2 Z710 in the Rohde & Schwarz RF Shield Box and Coupler

The following values shall be used when testing the Sony Ericsson Z710 in the Rohde & Schwarz RF shield box (**R&S part # 1150.1008.02**) using the Rohde & Schwarz coupler (**R&S part # 1150.0801.02**) and RF-cable (**SEMC part # RPM 119 855**). A precision type N Male to SMA Female adapter is required to connect the cable to the RF shield box.

Band	Channel*	Attenuation	
		RX	TX
GSM 850	Low	12.70	19.00
	Mid	11.70	18.27
	High	10.80	16.64
GSM 900	Low	10.90	11.70
	Mid	12.80	9.44
	High	14.60	9.65
GSM 1800	Low	10.15	12.80
	Mid	11.05	12.21
	High	12.40	11.06
GSM 1900	Low	15.90	11.47
	Mid	18.10	12.09
	High	21.65	14.74

* See Channel Allocation Table



4.3 W710 and Z710 with the RF fixture (Conducted)

The following values shall be used when testing the Sony Ericsson W710 or Z710 with the RF Fixture. The set up shall consist of a RF cable (**SEMC part # RPM 119 855**), RF probe (**SEMC part # RPM 119 0201**) and RF probe holder (**SEMC part # NTZ 112 1072**).

Band	Channel*	Attenuation	
		RX	TX
GSM 850	ALL	0.80	0.80
GSM 900	ALL	0.80	0.80
GSM 1800	ALL	1.30	1.30
GSM 1900	ALL	1.30	1.30

* See Channel Allocation Table

5 Revision History

Rev.	Date	Changes / Comments
A	2006-08-28	Initial Release