

Equipment List, Electrical

Applicable for W960

Contents

1	General	2
2	Column Definitions	2
2.1	Description Columns	2
2.2	Process Columns	2
3	Repair Equipment, Electrical.....	3
3.1	Sony Ericsson-Provided Repair Equipment	3
3.2	Equipment Provided by Other Supplier	7
3.3	Lead-free Solder Equipment	17
4	Revision History	20

1 General

This document describes the equipment needed, in addition to the equipment listed in the Mechanical Equipment List, to upgrade the applicable product(s)'s software, functional test and to repair the product(s) at an Electrical Repair Level. The first section is equipment that can be purchased from a Sony Ericsson Parts and Tools warehouse. The second section is equipment that must be purchased from other vendors.

2 Column Definitions

2.1 Description Columns

- Description = The name of the equipment.
- Part Number = The Sony Ericsson part number to use when ordering from a Sony Ericsson Parts and Tools warehouse.
- Comments = Additional information that helps to specify or clarify the equipment.




2.2 Process Columns




These columns show which processes use the equipment. An "X" in a column indicates that the equipment must be used, and a "Z" in a column indicates that the use of that equipment is optional.




- Test = A manual and/or automated method of evaluating the functionality of a phone.
- Repair = A method of fixing a phone.


3 Repair Equipment, Electrical

3.1 Sony Ericsson-Provided Repair Equipment


					Test	Repair
Pos	Description	Part Number	Comments	Picture		
	Sony Ericsson Programming Interface (SEPI)	LTN 214 1484	The Sony Ericsson Programming Interface (SEPI) is used in conjunction with the SEPI-A1 interface cable, the USB computer cable and battery charger to perform calibration on this product.			X
	Sony Ericsson Programming Interface (SEPI-A1) cable	KRY 101 1119/1	A battery charger needs to be connected to this cable during calibration.			X
	RF Cable	RPM 119 855			X	X

Pos	Description	Part Number	Comments	Picture	Test	Repair
	Battery Eliminator	NTZ 112 533	If using the Battery Eliminator to power the handset during the GNG Test or Calibration routine you must use a high quality DC source.		Z	Z
	Rework Fixture for PCB	LTD 260 273	Used to hold the PCB during repair.			X
	Antenna Connector	RNT 403 303/001			X	X

Pos	Description	Part Number	Comments	Picture	Test	Repair
	RF-Holder	1203-2911			X	X
	RF Test Cable Flexible 1M	RPM 119 855	This is the only approved RF cable!		X	
	USB Activation Dongle	NTZ 112 1071				X

Pos	Description	Part Number	Comments	Picture	Test	Repair
	Shield Fence Plier	NTZ 112 537	For use when repair under shield fence is necessary			X

3.2 Equipment Provided by Other Supplier

Pos	Description	Comments	Picture	Test	Repair
27	Battery Charger (Standard SEMC charger applicable for W960)	The battery charger needs to be connected to the Sony Ericsson Programming Interface Cable during calibration.			X
43	USB Computer Cable	Type A to Type B USB cable. This is part of the hardware needed for performing calibration.			X

Pos	Description	Comments	Picture	Test	Repair
	Agilent 8960 Required Components: <ul style="list-style-type: none"> • E5515C (8960 Series 10 Mainframe) • Option E5515C-002 (2nd RF source) • Option E5515C-003 WCDMA HW Option • Option E5515C-201 GSM and GPRS Func. Required Software <ul style="list-style-type: none"> • E1985B TA Fast switching • E1963A WCDMA Test application 	Some older versions of the 8960 Series 10 mainframes may need to have a hardware upgrade in order to have WCDMA capabilities. See your local Agilent representative for details. <i>Note: It is strongly recommended that the instrument vendor be contacted before ordering this setup to ensure that the options stated are still valid or that no part numbers have changed.</i>		X	X
	Willtek 4403/4405/4407 Required Components: <ul style="list-style-type: none"> • Firmware 4.21 or greater • The 4403 instrument needs to have option # M897163 installed. 	<i>Note: It is strongly recommended that the instrument vendor be contacted before ordering this setup to ensure that the options stated are still valid or that no part numbers have changed.</i>		X	X



Pos	Description	Comments	Picture	Test	Repair
	Rohde & Schwarz CMU200 Required Components <ul style="list-style-type: none"> • CMU200 mainframe (Base Unit) • Options CMU-B11, CMU-B21, CMU-B52, CMU-B54 • Required SW package: CMU-PK20 	Note: It is strongly recommended that the instrument vendor be contacted before ordering this setup to ensure that the options stated are still valid or that no part numbers have changed.		X	X
77	Power Supply (w/digital readout) NOTE! If using the Power Supply in conjunction with the Battery Eliminator (Dummy Battery) to power the phone during the GNG test or Calibration routine a high quality DC source that meets the following requirements <u>must</u> be used.	Device Requirements: <ul style="list-style-type: none"> • Output Voltage: 0-5 volt minimum. • Output Current: 0-2 amps minimum. • Transient response time: < 100 μs Some examples of Power Supplies that meet these requirements are as follows: <ul style="list-style-type: none"> • Agilent 66xx series • Agilent 663x series 		Z	Z

Pos	Description	Comments	Picture	Test	Repair
78	Small Convection (Hot Air) Device	Device Requirements: <ul style="list-style-type: none"> The device should allow variable adjustment over a temperature range. The device should be capable of reaching an upper temperature of 426.7°C (800°F) or more. The range of airflow the device is capable of generating should fall under 20 litre/minute.			X
79	Large Convection (Hot Air) Device	Certain components on the parts list can only be replaced using this device. These parts are specified in the parts list. <ul style="list-style-type: none"> The device should allow variable temperature adjustment and be capable of reaching an upper temperature of 426.7°C (800°F) or more. The range of airflow the device is capable of generating should be above 20 litre/minute. 			X

Pos	Description	Comments	Picture	Test	Repair
80	Nozzles for Large Convection (Hot Air) Device	NOTE: Only necessary if you have a large convection device.			X
81	Digital Multi-meter	Used for troubleshooting failures			Z
82	Microscope	Minimum magnification required is 10x			X
83	GPIB Card	National Instruments or Keithley NOTES: <ul style="list-style-type: none"> • Drivers are required and should be supplied with a card. • A GPIB card is not required if testing is being performed using the Willtek 420x instrument. 		Z	X
84	GPIB Cable	This cable is only required if a GPIB card is used.		Z	X




Pos	Description	Comments	Picture	Test	Repair
88	Power cable – Red NOTE: Only necessary if using the Battery Eliminator (Dummy Battery).	Cable Requirements: <ul style="list-style-type: none"> • Minimum cross sectional area of conductor = 1.2mm² • Maximum length = 1.5 m • One end of cable must have a male banana-type connector to be able to interface with the battery eliminator. • The other end of the cable needs whatever connection is necessary to connect to the power supply that you have. 		Z	Z
89	Power cable – Black NOTE: Only necessary if using the Battery Eliminator (Dummy Battery).	Cable Requirements: <ul style="list-style-type: none"> • Minimum cross sectional area of conductor = 1.2mm² • Maximum length = 1.5 m • One end of cable must have a male banana-type connector to be able to interface with the battery eliminator. • The other end of the cable needs whatever connection is necessary to connect to the power supply that you have. 		Z	Z

Pos	Description	Comments	Picture	Test	Repair
90	Component baking oven	<p>Temperature requirements: 125°C +5°C/-0°C</p> <p>Required for drying moisture sensitive components.</p> <p>Below are links to several companies that sell convection ovens.</p> <p>http://www.cascadetek.com/forcedlist.php</p> <p>http://www.wisoven.com/lab1.htm</p> <p>http://www.shellab.com/products.html</p> <p>http://www.terrauniversal.com/products/ovens/imperiaivmechcon.php</p> <p>http://www.labsynergy.com/products_laboratoryovens.asp?keyword=*laboratoryovens</p>			X



Pos	Description	Comments	Picture	Test	Repair
91	RF Shield Package Rohde & Schwarz RF Shield Package <ul style="list-style-type: none"> CMU-Z10 – Shield box CMU-Z11 – Antenna Coupler 	Using an RF shield package is one of the options for testing the applicable product(s). Testing of the applicable product(s) can also be performed by using the combination of an RF Probe (POS 62), Holder RF Connector (POS-63) and an RF cable (POS 51). NOTE: The Rohde & Schwarz package will require the use of a precision N-type male to SMA female RF adapter to mate with the SEMC RF cable (see POS 110 for adapter ordering information).		Z	
	Flux	Lead-free solder does not require a special flux. The “No Clean” flux used with leaded products is acceptable. Although some manufacturers are developing fluxes specially made for use with lead-free solder (higher evaporation temperatures, less smoke, etc.), these are not required.			X





Pos	Description	Comments	Picture	Test	Repair
	Low Static Heat Protection Tape	This tape is required to protect adjacent components from hot air.			X
96	Computer	<p>One of the following operating systems must be used:</p> <ul style="list-style-type: none"> • Windows 2000 with service pack 2 or higher • Windows XP <p>Minimum Requirements:</p> <ul style="list-style-type: none"> • One unused PCI slot for GPIB card • 3 USB Ports • The processor and RAM of the computer should at least meet the the minimum requirements specified by the operating system's manufacturer. 		Z	X
99	Test U-SIM	According to your Instrument supplier		X	
109	Printer	Optional, but recommended		Z	Z


Pos	Description	Comments	Picture	Test	Repair
110	RF adapter for RF shield box <ul style="list-style-type: none"> The adapter for a Rohde & Schwarz Shield box must be a precision N-type male to SMA female adapter. 	This adapter is used to connect the RF shield box to the RF cable and is only required if a shield package is going to be used for testing. Recommended source: <ul style="list-style-type: none"> Pasternack Enterprises – (949) 261-1920 or www.pasternack.com Part number: PE9430 		Z	

3.3 Lead-free Solder Equipment

The items in this table, and any other soldering tools or material that make physical contact with the solder, must remain lead-free. They must be adequately labelled to make their lead-free status clearly and easily recognized.

				Test	Repair
Pos	Description	Comments	Picture		
	<p>Lead-free Solder</p> <p>Note: The solder must be composed of Tin, Silver, and Copper, and nothing else. The exact composition ratio may vary, but it must be Tin, Silver, and Copper only. This composition may also be known as SnAgCu or SAC.</p>	<p>Manufacturers of LF Solder:</p> <ul style="list-style-type: none"> - Tamura (www.tamura-kaken.co.jp) Part # TLF-206-93F - Multicore (www.multicore.com) Part # 96SC - Senju (www.senju-m.co.jp) Part # M705 			X
	<p>Lead-free labels (sheet of 24)</p> <p>SEMC Part # SVF9301379 (These labels are available from the Sony Ericsson Parts and Tools Warehouse.)</p>	<p>Required for labeling all soldering tools and materials that contact the solder.</p>			X

				Test	Repair
Pos	Description	Comments	Picture		
	Soldering Tips				X
	Soldering Iron If one work bench is divided to accommodate both leaded and lead-free solder, then each side of the bench should have its own iron.	<ul style="list-style-type: none"> The device should allow variable temperature adjustment and be capable of reaching an upper temperature of 426.7°C (800°F) or more. 			X
	Wicking Tape				X
	Tip Tinner				X

Pos	Description	Comments	Picture	Test	Repair
	Tip Cleaner (steel wool)				X

4 Revision History

Rev.	Date	Changes / Comments
1	2007-11-29	Initial Release
2	2007-12-05	Added RF-holder picture